

MISE A JOUR DU LOGICIEL INTERNE

1. Pour mettre à jour l'enregistreur : copier le fichier fourni dans la racine d'une clef USB **vierge** (aucun autre fichier dedans).
2. Placez celle-ci sur l'un des connecteurs USB à l'arrière de l'appareil.

Config.

3. Appuyez sur la touche **Config.** puis sélectionner la ligne de paramètres « **Modification version** » puis touche F1 « **modif** » pour valider.
Le logiciel interne copie alors automatiquement les fichiers nécessaires à la nouvelle version.
4. Faire un arrêt / marche lorsque la fin de la mise à jour est terminée.

UPDATING THE INTERNAL SOFTWARE

1. For the updating : copy the file furnished into the root of a **virgin** USB key (no other files inside).
2. Place it on one of the USB connectors at the rear side of the appliance.

Set up

3. Push on the **Set up** key, then select the parameter line « **Software update** » and validate with F1 « **Modify** ».
The internal software will automatically copy the required files in the new version.
4. Turn off and on after the updating is complete.

