



## Procedure to update the software of 7861, 7862, 7863, 7865 or 7866

(abstract of the user manual)

### 4.6 Updating the software

The embedded software can be updated to get new features developed by SEFRAM.

- download from our web site ([www.sefram.fr](http://www.sefram.fr)) , the update software 786X\_vX.X.ZIP
- Connect a USB memory stick to your computer.
- Extract the file in the USB memory stick
- Remove the USB memory stick 
- Power on the instrument and check that the battery has a minimum 30% charge (if not please charge the battery before upgrading)
- Connect the USB memory stick to the TV Meter. The updating process will start automatically



- **Caution : do not power-off the instrument during firmware update**



- When updating is completed, disconnect the USB memory stick and restart your TV Meter.



The software is loaded in your appliance.

Error messages may appear, do not take account of this.

At the end of the update, turn off and then turn on the appliance.